




### RMAE




$ac = 0.33, \alpha_2 = 0.25, \alpha_1 = 0.2475, T = 75$




$ac = 0.33, \alpha_2 = 0.25, \alpha_1 = 0.2475, T = 250$




$ac = 0.33, \alpha_2 = 0.25, \alpha_1 = 0.2475, T = 2500$




$ac = 0.33, \alpha_2 = 0.35, \alpha_1 = 0.2145, T = 75$




$ac = 0.33, \alpha_2 = 0.35, \alpha_1 = 0.2145, T = 250$




$ac = 0.33, \alpha_2 = 0.35, \alpha_1 = 0.2145, T = 2500$



$ac = 0.33, \alpha_2 = 0.45, \alpha_1 = 0.1815, T = 75$




$ac = 0.33, \alpha_2 = 0.45, \alpha_1 = 0.1815, T = 250$




$ac = 0.33, \alpha_2 = 0.45, \alpha_1 = 0.1815, T = 2500$


### RMAE




$ac = 0.55, \alpha_2 = 0.25, \alpha_1 = 0.4125, T = 75$




$ac = 0.55, \alpha_2 = 0.25, \alpha_1 = 0.4125, T = 250$




$ac = 0.55, \alpha_2 = 0.25, \alpha_1 = 0.4125, T = 2500$




$ac = 0.55, \alpha_2 = 0.35, \alpha_1 = 0.3575, T = 75$




$ac = 0.55, \alpha_2 = 0.35, \alpha_1 = 0.3575, T = 250$




$ac = 0.55, \alpha_2 = 0.35, \alpha_1 = 0.3575, T = 2500$



$ac = 0.55, \alpha_2 = 0.45, \alpha_1 = 0.3025, T = 75$



$ac = 0.55, \alpha_2 = 0.45, \alpha_1 = 0.3025, T = 250$



$ac = 0.55, \alpha_2 = 0.45, \alpha_1 = 0.3025, T = 2500$

### RMAE

